



INSTALLATION INSTRUCTIONS FLAT ROOF DOWNPIPE SET

- Cut the downpipes to the required size with a fine-toothed saw. Deburr rough edges with a knife or abrasive paper.
 - Thoroughly clean the parts that need gluing and make sure they are dry.
1. Make sure that the reducer $\text{Ø}70\text{-}\text{Ø}60\text{mm}$ completely fits over the roof outlet. If not, cut a piece off the outlet with a fine-toothed saw and place the reducer over the outlet.
 2. Determine where the downpipe should be installed. Install the first elbow on the reducer with a piece of downpipe. Also, the second elbow is connected to the first elbow by using a piece of downpipe.
 3. Please screw the pipe clips into the wall before installing the downpipes.
 4. Two pieces of downpipe can be connected with a pipe socket.
 5. Place the upper pipe clip ca. 20 cm under the second elbow. The second pipe clip can be installed ca. 25-30 cm above the ground.
 6. If the downpipe system is not connected to the sewerage, the third elbow can be installed just above the ground to avoid the rainwater from splashing around.
 7. If everything is installed well, you can glue all parts with a PVC glue.