



INSTALLATION INSTRUCTIONS FLAT ROOF DOWNPIPE SET ZINC

- Please make sure that you read all the installation instructions before you start assembling.
- During installation use gloves for protection.
- Downpipes can be cut to size with a hacksaw.

1. Make sure that the first elbow completely fits over the roof outlet. If not, cut a piece off the outlet (plastic) with a fine-toothed saw and place the elbow over the outlet.
2. Determine where the downpipe should be installed. The first elbow and the second elbow fit into each other. But it is also possible to put a piece of downpipe between the first and the second elbow.
3. Please screw the pipe clips into the wall before installing the downpipes.
4. Two pieces of downpipe fit into each other.
5. Place the upper pipe clip ca. 20 cm under the second elbow. The second pipe clip can be installed ca. 30-35 cm above the ground.
6. If the downpipe system is not connected to the sewerage, the third elbow can be installed just above the ground to avoid the rainwater from splashing around.

